




ASSEMBLY INSTRUCTIONS

ADJUSTABLE LENGTHS

STEP 1: Pre-assemble the LOCKING BAND (D) in the ADJUSTABLE LENGTH.

STEP 2: Fit the MALE (A) of the ADJUSTABLE LENGTH into the FEMALE (B) of the previous item and adjust the length to the required distance.



STEP 3: Fix the LOCKING BAND (D) over the fitting to guarantee the required length